# **OPERATING MANUAL**

Model/Series: 6000 Number: 040-561 GB Version: 2018-11



# **Rotating Unions**



Series				
6000	6005			
Model				
6200 6250 6300 6400	6205 6255 6305 6405			

Rev. C ©DEUBLIN



Model/Series: 6000 Number: 040-561 GB Version: 2018-11

# Content

1 F	or your Safety	3
1	.1 Intended Use	
1	.1.1 Application one-way version (Mono)	
1	.1.2 Application two-way version (Duo)	
	.2 Misuse	
	.3 Safety Instructions	
	.3.1 Hazards due to hot surfaces	
	.3.2 Hazards by incorrect hoses	
	.3.3 Hazards due to the media	
	.3.4 Hazards by faulty installation  .4 Structure of Pictograms	
-	nformation as to this Manual	
	nformation on the Name Plate	
	nformation on the Design	
	.1 Filtering of the Medium	
	.2 Connecting Options of the Rotating Union at the Machine Shaft	
4	.3 Options of Hose Installation	
4	.3.1 Connection of hose to the rotating union	
4	.3.2 Hose connection for hoses with SAE flange	9
5 Ir	nstallation	9
6 Ir	nformation on the Operation	9
7 S	Storage	9
8 N	flaintenance	10
8	.1 Maintenance Intervals	10
	.2 Daily Inspection	
	.3 Maintenance after Operating Hours	
	.3.1 Allowed lubricants	
	.3.2 Volume of grease for lubrication	
	.3.3 Relubrication intervals for series 6000	
	.3.4 Relubrication intervals for 6005	
	rouble Shooting	
	.1 Potential Causes for Errors and their Elimination	
	.2 Pack Rotating Union for Transport	
10 D	Disposal	
	0.1 Dispose of Packaging	
	0.2 Dispose of Rotating Union	
11 S	Spare Parts	15



Model/Series: 6000 Number: 040-561 GB Version: 2018-11

### 1 For your Safety

This chapter provides information on the safe handling of DEUBLIN rotating unions.

- ☐ For your own safety and the safety of other people read this operating manual carefully and completely prior to working on or with *DEUBLIN* rotating unions.
- ☐ This operating manual exclusively describes the rotating unions of the manufacturer *DEUBLIN*. In the further description/explanation the name "*DEUBLIN*" is left out for a better readability.
- ☐ This operating manual is a material part of the specified rotating unions. The operator is responsible for the personnel to take note of this manual.
- ☐ The operator of the rotating unions shall not make any modifications or attachments to and retrofitting of the rotating union without the manufacturer's consent.

### 1.1 Intended Use

The rotating unions of the series 6000 and 6005 supply the feeding of the following media: Water and Thermal oil (not all designs of series 6000 are suitable for thermal oil. If you want to use a series 6000 model for thermal oil, please contact *DEUBLIN*.)

		Temperature	Med	Medium		
Series	Model	range (°C)	Water	Thermal oil		
6000	6200	up to 120°	1	Х		
6005	6205	up to 160°	✓	✓		
6000	6250	up to 120°	✓	X		
6005	6255	up to 160°	✓	✓		
6000	6300	up to 120°	✓	×		
6005	6305	up to 160°	1	1		
6000	6400	up to 120°	1	Х		
6005	6405	up to 160°	1	1		

The rotating unions referred to are designed for non-potentially explosive environments and non-combustible media. Details on the operating range of the rotating unions are provided in the catalogue and/or the model-specific installation drawing.

The rotating unions of the series 6000 and 6005 can be used as one-way or two-way version depending on the type of connection.



Model/Series: 6000 Number: 040-561 GB Version: 2018-11

### 1.1.1 Application one-way version (Mono)

For the one-way version, models are available which can be installed at the machine shaft from the outside or in the machine shaft.

### Rotating union externally mounted




Fig. 1: Schematic diagram one-way version (Mono – externally mounted)

One one-way version of the rotating union is mounted at each of the two ends of the roller. The rotating union **(A)** conveys the medium into the roller. The rotating union **(B)** conveys the medium into the piping system of the machine.

### 1.1.2 Application two-way version (Duo)




Fig. 2: Schematic diagram two-way version (Duo)

The rotating unions of the 6000 and 6005 series are also available as two-way model (Duo).

Through the elbow, the medium is guided through a supply tube into the machine shaft. The escaping medium is collected by the same rotating union and fed into the piping system of the machine through the radial connection.

### 1.2 Misuse

This chapter provides information on known misuse of rotating unions of the 6000 and 6005 series. The rotating unions are not suitable for the areas and applications described herein. Use in such areas or for such applications constitutes a misuse endangering people and machines and is therefore prohibited.

### Prohibition for the following areas:

### ☐ Potentially explosive areas

The rotating unions of the 6000 and 6005 series shall not be used in potentially explosive areas, as they are not approved for the requirements in potentially explosive areas. Operation in such areas may cause explosions.

### ☐ Food

Food, cleaning and disinfectant residues cannot be removed from the rotating unions. People may suffer poisoning.



Model/Series: 6000 Number: 040-561 GB Version: 2018-11

### Prohibition for the following applications:

<b>y</b>
Conveying of combustible media or hydrocarbons Combustible media or hydrocarbons may ignite or cause explosions.
Connection to a piping system with excessive pressure  If excessive pressure is applied to the rotating unions, supply pipes can come off and cause personal injury or property damage.
Operation without lubrication  Dry operation (without medium) of the rotating union causes damage to the axial face seals.
Connection to fixed pipes If connection is via fixed pipes, the rotating unions may leak and the ball bearings may get damaged.
Conveying of media which are too hot  If the media exceed the maximum admissible temperature for the rotating union, the static seals (elastomeric seals) can be damaged which may result in leaky rotating unions and personal injury or property damage.
Conveying of vapour

This list is not comprehensive and will be updated with results from product observation.

### 1.3 Safety Instructions

This chapter provides information on the hazards through rotating unions.

Escaping vapour may injure people seriously.

### 1.3.1 Hazards due to hot surfaces

The rotating unions are heated by the temperature of the medium. Skin contact with heated rotating unions can cause injuries.

Use safety gloves and PPE (Personal Protective Equipment) protecting against heat when han-
dling the rotating union.

□ Attach a clearly visible danger sign visibly on/next to the rotating union in order to warn of danger.

### 1.3.2 Hazards by incorrect hoses

For the connection of the rotating union to the machine, you have to choose appropriate hoses for the respective medium, which meet, the specifications for the application.

If you use incorrect hoses, the latter may become porous or burst. This can cause personal injury and/ or property damage to components of the machine.

☐ In case of the media water and thermal oil, use hoses which are suitable for the maximum system pressure of the machine and the maximum temperature of the media.

### 1.3.3 Hazards due to the media

When working on the rotating union, injuries can be caused by skin or eye contact with the media.

☐ Observe the safety instructions for the flow media. Observe the COSHH Safety Data Sheet for the flow media.



Model/Series: 6000 Number: 040-561 GB Version: 2018-11

### 1.3.4 Hazards by faulty installation

If the rotating unions are installed incorrectly, hoses and connections may become leaky. The medium can escape. Depending on the medium, personal injury or property damage to the components of the machine may occur.

Before installing the rotating	g union	ensure	that n	o feed	pressure	and n	o residual	pressure	is
applied to the pipeline syst	em of th	e machi	ne.						

- ☐ Install the rotating union on the machine using hoses only, in order to avoid stress on the rotating union.
- Install the hoses free from stress.
- ☐ Install the hoses to the rotating union prior to mounting it at the machine shaft. Hoses with SAE connection are excluded.

### 1.4 Structure of Pictograms

This chapter provides information on the meaning of the pictograms used in the manual.



### Warning

Potentially dangerous situation, which may result in death or serious injury.



### Note

Potentially harmful situation in which the product or surrounding objects can be damaged.



### **Application notes**

and other useful information.

### 2 Information as to this Manual

The copyright as to this manual remains with DEUBLIN. Subject to changes!

- ☐ You can download the latest version of this manual under www.deublin.eu.
- ☐ Always use the latest version of the operating manual.



# **DEUBLIN**° | Operating Manual

Model/Series: 6000 Number: 040-561 GB Version: 2018-11

### 3 Information on the Name Plate



Model number

DEUBLIN's internal identification / date of manufacture

MADE IN <<country of manufacture>>

Fig. 3: Name plate

The coding of the model number is described in the catalogue.

### 4 Information on the Design

This chapter provides information as to which items have to be observed in the design in order to have a positive effect on the service life of the rotating union.



You can obtain the drawings of the rotating unions from *DEUBLIN* in order to integrate the rotating union in your drawing.

### 4.1 Filtering of the Medium

Unfiltered media with a particle size of more than 60 µm result in increased wear of the rotating union.



The larger the particles in the media, the higher the wear of the rotating union is.

Insert a filter in front of the rotating union which filters particles with a size of 60 μm and larger from the media.



# **DEUBLIN**° | Operating Manual

Model/Series: 6000 Number: 040-561 GB Version: 2018-11

### 4.2 Connecting Options of the Rotating Union at the Machine Shaft




Fig. 4: Options for the installation on the machine shaft

The rotating unions can be fastened on the machine shaft by screwing **(A)** or by means of a flange **(B)** depending on the rotating union.

### 4.3 Options of Hose Installation

The following examples show how to install the hoses at the rotating unions.

These connecting options ensure that the hoses do not transfer stress to the rotating unions when the machine shaft moves.

☐ Please pay attention to the chapter "1.3 Security Advices" regarding the design.

### 4.3.1 Connection of hose to the rotating union

The hoses must be installed without stress and bends so that they do not apply any forces to the rotating union. The following figures show examples of installation.



Fig. 5: Hoses bent by 90°

If the hoses are to be guided away from the rotating unions vertically and bent by 90°, connect the hoses as shown.



# **DEUBLIN**<sup>®</sup> Operating Manual

Model/Series: 6000 Number: 040-561 GB Version: 2018-11

### 4.3.2 Hose connection for hoses with SAE flange



Only possible, if the rotating union is ordered with SAE connections.



The hoses are fastened at the rotating union by means of its SAE flanges using four screws.

Fig. 6: Flange connection

### 5 Installation

The union installation is described in an additional manual which is supplied with each rotating union. Please follow the additional instruction "Installation" for a secure and correct installation of the rotating union. The instruction "Installation" is available online under www.deublin.eu.

- ☐ Ensure that the person installing the rotating union receives the following information:
  - Position and location of the rotating union in the machine
  - Plan for connection of hoses
  - Position of leakage line
  - Information on the media

### 6 Information on the Operation



### Damage to components due to missing lubrication (Dry run)

The axial face seals of the rotating unions are lubricated by the medium. If the rotating unions are operated without medium present they are not lubricated and will thus be damaged.

- ☐ Ensure that the rotating unions are operated with a medium.
- ☐ Switch off the plant/machine, if the rotating unions are operated without medium.

## 7 Storage



### Damage of component due to incorrect storage

If you store the rotating unions incorrectly, they become leaky or get damaged.

- ☐ Store the rotating unions in a dry space between 3 °C and 40 °C.
- ☐ Store rotating unions for two years at the most.



Model/Series: 6000 Number: 040-561 GB Version: 2018-11

### 8 Maintenance

This chapter provides information on how to extend the service life of the rotating unions by means of maintenance.

### 8.1 Maintenance Intervals

You can avoid early wear of the rotating unions, if you adhere to the maintenance intervals described herein.



### Risk of injury due to hot or cold surfaces

The rotating unions are heated or cooled by the temperature of the medium. Skin contact with these heated or cooled rotating unions can cause severe injuries.

- ☐ Before starting to work on the rotating union, allow the machine to cool down.
- ☐ Use safety gloves and PPE (Personal Protective Equipment) protecting against heat or cold depending on the application of the rotating unions.

### 8.2 Daily Inspection

Check the rotating unions for tightness.



### Risk of injuries due to applied line pressure

If you have to work on the rotating union and feed pressure of the medium is applied or there is residual pressure in the piping system of the machine, the medium can escape under pressure when releasing the connections. You and other people may suffer severe injuries.

- ☐ Ensure that no feed pressure is applied.
- ☐ Ensure that there is no residual pressure in the piping system.




Fig. 7: Inspect visually

During operation of the machine, leakages may occur at the connections and hoses depending on the requirements to the rotating unions.

☐ Carry out daily visual inspections in order to check whether leakages occurred at the connections (see arrows).

If you detect leakage:

- 1. Stop the machine.
- 2. Replace the defective hoses with new ones.
- 3. Seal leaking connections.
- 4. If the rotating union is worn and leaks, replace it with a new one. Repair kits for various models can be obtained from *DEUBLIN*.

### 8.3 Maintenance after Operating Hours

This chapter describes how to relubricate the rotating unions.



The indicated volumes of grease and intervals for relubrication are based on experience resulting from the information of the manufacturer of the lubricant and the operating parameters of the rotating unions. The information given herein refers to operating hours depending on the respective speed.

☐ In case of doubt, consult *DEUBLIN*.



# DEUBLIN Operating Manual

Model/Series: 6000 Number: 040-561 GB Version: 2018-11

Lubricate the ball bearings of the rotating unions at the stated lubricating intervals using the listed volume of grease suitable for the operating conditions. If you do not adhere to these instructions, the service life of the ball bearings is reduced.

### 8.3.1 Allowed lubricants

Series	allowed lubricants	
6000	TEXACO CHEVRON SRI 2 GREASE NLGI 2	
6005	DUPONT KRYTOX XHTRUF	
	KLÜBER BARRIETA L55/0	
	LUBCON TURMOTEMP II/400	

### 8.3.2 Volume of grease for lubrication



### Damage to the component due to excessive grease

If you put too much grease in the ball bearings, the latter can be damaged.

☐ Adhere to the stated volumes of grease for lubrication.

Series	Model	Volume of grease (g)
6000	6200	18
	6250	42
	6300	68
	6400	90

Series	Model	Volume of grease (g)		
6005	6205	72		
	6255	136		
	6305	285		
	6405	508		


### 8.3.3 Relubrication intervals for series 6000

The intervals for relubrication depend on the operating conditions of the rotating unions.

### Relubrication intervals for light duty operating conditions

Light duty operating conditions are:

- ☐ Medium with a temperature of max. 75°C
- ☐ Few vibrations
- ☐ Little humidity
- ☐ Hardly polluted environment






Model/Series: 6000 Number: 040-561 GB Version: 2018-11

### Relubrication intervals for medium-heavy duty operating conditions

Medium-heavy duty operating conditions are:

- ☐ Medium with a temperature of 75° to 120°C
- many vibrations
- much humidity
- extremely polluted environment



### Relubrication intervals for extreme operating conditions

If the operating conditions exceed the easy and medium-heavy operating conditions, the lubrication interval, volume of grease and grease type have to be adapted to the application.


☐ Please consult your lubricant supplier.

### 8.3.4 Relubrication intervals for 6005

The relubrication intervals depend upon the conditions of use of the rotating unions.

### Scope:

These instructions apply to *DEUBLIN* series 6005 and show the relubrication intervals as well as the required quantities when using the following lubricating greases: KLÜBER BARRIERTA L55/2, LUBCON TURMOTEMP II/400 or DUPONT KRYTOX XHTRUF GREASE.





# DEUBLIN Operating Manual

Model/Series: 6000 Number: 040-561 GB Version: 2018-11

### Relubrication:

Lubrication quantities with KLÜBER BARRIERTA L55/2, LUBCON TURMOTEMP II/400 or DUPONT KRYTOX XHTRUF GREASE:

Model 6205: 72 g Model 6255: 136 g Model 6305: 285 g Model 6405: 508 g

The above values are taken from the information of the lubricant manufacturers and/or their documents.

The actual quantities and intervals are dependant upon the respective conditions of use and require experience gained in respect of the special application.

The relubrication intervals should be started cautiously and then be increased gradually based on the previous values.

### 8.3.5 Lubricate the rotating union



Fig. 8: Attach grease gun for relubrication

The following paragraphs describe how to place the grease gun and inject the stated volume of grease into the ball bearing.

- 1. Attach the grease gun to the lubricating nipple (see arrow).
- 2. Ensure that the connector of the grease gun is placed correctly on the lubricating nipple.
- 3. Actuate the grease gun in order to inject the stated volume of grease into the ball bearing.
- 4. Count the operating hours for the following lubrication interval.

### 9 Trouble Shooting

This chapter provides the following information:

- 1. Which problem may occur?
- 2. What can be the cause of the problem?
- 3. How can you eliminate this problem?

### 9.1 Potential Causes for Errors and their Elimination



### Risk of injuries due to applied line pressure

If you have to work on the rotating union and feed pressure of the medium is applied or there is residual pressure in the piping system of the machine, the medium can escape under pressure when releasing the connections. You and other people may suffer serious injuries.

- ☐ Ensure that no feed pressure is applied.
- ☐ Ensure that there is no residual pressure in the piping system.



Model/Series: 6000 Number: 040-561 GB Version: 2018-11

Error	Potential causes	Elimination			
Rotating union is leaky after installation	Incorrect installation	<ol> <li>Stop the machine.</li> <li>Ensure that the connections are sealed according to the manual "Installation".</li> <li>Ensure that all hoses are installed without stress.</li> <li>Ensure that all seal faces are clean.</li> </ol>			
	Seal faces of the rotating union are damaged	<ol> <li>Pack rotating union</li> <li>Send rotating union to <i>DEUBLIN</i> for over-</li> </ol>			
	Rotating union is defective	haul/service.			
Rotating union leaks before the end of the expected service life	Medium is contaminated	<ol> <li>Stop the machine.</li> <li>Drain medium.</li> <li>Send rotating union to <i>DEUBLIN</i> for overhaul/service, if required.</li> <li>Mount new filter.</li> <li>Flush the piping system of the machine.</li> <li>Fill in new medium.</li> </ol>			
	Rotating union is not designed for the respective application	<ol> <li>Ensure that the correct <i>DEUBLIN</i> Rotating Union is used.</li> <li>Contact <i>DEUBLIN</i> if required.</li> </ol>			
Rotating union runs untrue or wobbles	Thread and/or concentricity outside the admissible tolerance.	<ol> <li>Stop the machine.</li> <li>Remove rotating union.</li> <li>Manufacture new thread or flange.</li> </ol>			
	Rotating union is mounted incorrectly.	4. Install rotating union.			

### 9.2 Pack Rotating Union for Transport

The rotating union has to be protected against mechanical impact and humidity during transport to ensure that the rotating union will arrive at *DEUBLIN* without being damaged.



### Risk of injury by high weight

The rotating unions are heavy (depending on the model > 25 kg).

If you lift the rotating unions on your own or without a lifting device, you and other people may suffer injuries.

- ☐ Always install the rotating union in pairs.
- ☐ Use a crane or lifting device for transport and installation of the rotating union.
- 1. Dismount the rotating union in reverse order of the installation (see Installation).
- 2. Ensure that the rotating union is free from the respective media.
- 3. Use a cardboard box which is suitable for the weight of the rotating union.
- 4. Cushion the base of the cardboard box with a soft material, e.g. air bubble film.
- 5. Wrap the rotating union with a soft material, e.g. air bubble film.
- 6. Ensure that no packing material or dirt can penetrate the opening of the rotating union.
- 7. Position the rotating union in the middle of the cardboard box.
- 8. Fill the free space around the rotating union with newspaper or another suitable material.
- 9. Close the cardboard box by means of tape.



Model/Series: 6000 Number: 040-561 GB Version: 2018-11

### 10 Disposal



### Risk of injury by high weight

The rotating unions are heavy (depending on the model > 25 kg).

If you lift the rotating unions on your own or without a lifting device, you and other people may suffer injuries.

- ☐ Always install the rotating union in pairs.
- ☐ Use a crane or lifting device for transport and installation of the rotating union.

### 10.1 Dispose of Packaging

☐ Dispose of the packaging (cardboard box and plastics) according to the national standards, regulations and directives.

### 10.2 Dispose of Rotating Union

Mainly, the rotating unions consist of metals, which can be reused within the reclamation of scrap. Decontaminate unions / parts and dispose of in an "Environmentally Friendly" way.

- ☐ Dismount the rotating union in reverse order to the installation (see Installation).
- ☐ Flush the rotating union.
- ☐ Collect the dirty flushing media.
- ☐ Dispose of the collected flushing media according to the national standards, regulations and directives.
- ☐ If you use thermal oil, please observe the instructions of the thermal oil manufacturer.
- ☐ Dispose of the rotating union according to the national standards, regulations and directives.

In case of repair, DEUBLIN disposes of all used parts.

### 11 Spare Parts

The rotating unions have a limited service life and include wearing parts. Wearing parts are excluded from the warranty. All static and dynamic sealing elements of a component are considered wearing parts, as well as ball bearings.

Repair kits are available for several models of the rotating unions and can be obtained from *DEUBLIN*. Please ask your *DEUBLIN* Service.

You need special tools and repair instructions for repair of the rotating unions which can be obtained from *DEUBLIN* as well.



### Note

If you do not want to repair your rotating union on your own, *DEUBLIN* will be pleased to help you. If requested, *DEUBLIN* will exchange all wearing parts and clean all components of the rotating union. Before repaired rotating unions leave the premises, they will be subjected to an operational check. The repaired rotating union is returned with a standard "*DEUBLIN* Warranty" valid for 12 months.

# **©2018 DEUBLIN** GmbH | Florenz-Allee 1 | 55129 Mainz | Alle Rechte vorbehalten

### Reliability

Many years' experience, ongoing liaison with customers, innovations sourced inhouse and from suppliers place *DEUBLIN* in a position providing reliable Rotating Unions at the highest level.

When it comes to concrete applications, maximum service life is guaranteed by matching the sealing to the respective medium.

The service life is also equally maximized by maintaining cleanliness when storing and handling the Rotating Union and by adhering to the guidelines issued by *DEUBLIN* in respect of the conditions on the customer's premises.

### **EUROPE**

### **DEUBLIN** Germany

Florenz-Allee 1 55129 Mainz, Germany Phone: +49 6131-49980 Fax: +49 6131-4998109 e-mail: info@deublin.de

### **DEUBLIN** Italy

Via Guido Rossa 9 - Loc. Monteveglio 40053 Comune di Valsamoggia (BO), Italy Phone: +39 051-835611 Fax: +39 051-832091 e-mail: info@deublin.it

### **DEUBLIN** Austria

Lainzer Straße 35 1130 Wien, Austria Phone: +43 1-8768450 Fax: +43 1-876845030 e-mail: info@deublin.at

### **DEUBLIN** France

61 Bis, Avenue de l'Europe Z.A.C de la Malnoue, Emerainville 77436 Marne-la-Vallée Cedex 2, France Phone: +33 1-64616161

Fax: +33 1-64616364 e-mail: service.client@deublin.fr

### **DEUBLIN** Poland

ul. Bierutowska 57-59 51-317 Wrocław, Poland Phone: +48 71-3528152 Fax: +48 71-3207306 e-mail: info@deublin.pl

### **DEUBLIN** Russia

ul. Kosygina, 13, 5th entrance, 1st floor

Moscow, 119334, Russia Phone: +7 495-647 1434 Fax: +7 495-938 8949 e-mail: info@deublinrussia.ru

### **DEUBLIN** Spain

C/ Lola Anglada, 20 local 1 08228 Terrassa, Spain Phone: +34 93-221 1223 Fax: +34 93-221 2093 e-mail: deublin@deublin.es

### **DEUBLIN** United Kingdom

6 Sopwith Park, Royce Close, West Portway Andover SP10 3TS, UK

Phone: +44 1264-33 3355 Fax: +44 1264-33 3304 e-mail: info@deublin.co.uk

### **AMERICA**

### **DEUBLIN** USA

2050 Norman Drive Waukegan, IL 60085-6747 U.S.A Phone: +1 847-689 8600 Fax: +1 847-689 8690

e-mail: customerservice@deublin.com

### **DEUBLIN** Brazil

Rua Fagundes de Oliveira, 538 - Galpão A11 Piraporinha

09950-300 - Diadema - SP - Brasil Phone: +55 11-2455 3245 Fax: +55 11-2455 2358

e-mail: deublinbrasil@deublinbrasil.com.br

### **DEUBLIN** Mexico

Norte 79-A No. 77, Col. Claveria 02080 Mexico, D.F.

02080 Mexico, D.F. Phone: +52 55-5342 0362 Fax: +52 55-5342 0157

e-mail: deublinmexicocs@deublin.com

### **ASIA**

### **DEUBLIN** China

No. 2, 6th DD Street, DD Port Dalian, 116620, China Phone: +86 411-8754 9678 Fax: +86 411-8754 9679 e-mail: info@deublin.cn

### Shanghai Branch Office Room 15A07, Wangjiao Plaza

No. 175 East Yan'an Road, Huangpu District

Shanghai 200002

Phone: +86 21-5298 0791 Fax: +86 21-5298 0790 e-mail: info@deublin.cn

### **DEUBLIN** Asia Pacific

51 Goldhill Plaza #17-02 Singapore 308900 Phone: +65 6259-92 25 Fax: +65 6259-97 23 email: deublin@singnet.com.sg

### **DEUBLIN** Japan

2-13-1, Minamihanayashiki, Kawanishi City

Hyogo 666-0026, Japan Phone: +81 72-757 0099 Fax: +81 72-757 0120

e-mail: customerservice@deublin-japan.co.jp

2-4-10-3F, Ryogoku, Sumida-ku Tokyo 130-0026, Japan Phone: +81 35-625 0777 Fax: +81 35-625 0888

e-mail: customerservice@deublin-japan.co.jp

1-9-2-4F, Mikawaanjo-cho, Anjo City

Aichi 446-0056, Japan Phone: +81 566-71 4360 Fax: +81 566-71 4361

e-mail: customerservice@deublin-japan.co.jp

### **DEUBLIN** Korea

Star Tower #1003, Sangdaewon-dong 223-25, Jungwon-gu, Seongnam-si, Gyeonggi-do,

South Korea

Phone: +82 31-8018 5777 Fax: +82 31-8018 5780

e-mail: customerservice@deublin.co.kr